

Tecnoroll BMB srl

Via Olona 9, 21040 Vedano Olona VA

www.tecnoroll.it

FLEXMod-621

module

Connectors, pin description and programming protocol

Rev B, August, 28th 2012

Hardware revision 2.00

Firmware version 0.18

1. The use of this product in conformity with the DVB Standard is prohibited in any case, unless the license of patents applicable to the DVB patent group is granted.
2. It's the purchaser's duty to check which patents with potentially payable author's rights are used in his/her own final project and act accordingly with the bodies in charge.
3. The contents of this manual are subject to change without notice.
4. Of the specifications described in this manual, the functions and performance the supply of which is assured with this product are only those that can be confirmed with the separate Basic Firmware attached.
5. When the product or information described in this manual is used, our company does not guarantee or grant any license of the intellectual property rights and other rights of our company or of third parties. If any problems concerning the ownership rights of third parties attributable to the above use occur, our company will not be responsible for them.
6. Since the product described in this manual was not developed specially for equipment related to human life, those who intend to use it for equipment whose failure or malfunction may directly threaten human life or endanger the human body or for special applications requiring high reliability (such as aerospace, nuclear power control, submarine repeaters, travel control, and medical equipment for life support) must consult our sales responsible personnel in advance. Our company will not be responsible for any damages that may occur due to such use without consulting us.
7. Although our company is endeavoring to improve quality and enhance reliability, semiconductor products will fail with a certain probability. Users are requested to pay due attention to safe design techniques such as redundant design, preventive measures against the spreading of fire, over-current, and malfunctions, so that failure of the products described in this manual will not result in accidents leading to injury or death, fire, or social damage.
8. The product described in this manual is not designed to be radiation-resistant.
9. This board is just an 'electronic component' that cannot work in a standalone mode, therefore all the tests and qualifications for electromagnetic compatibility, all the CE certifications and any other regulations concerning the final product implemented by the customer are to be carried out by the customer himself referring to the final product for which this electronic component has been used.

Revision history:

Rev A, January, 10th 2011, abesani@tecnoroll.it

First release

Rev B, August, 28th 2012, abesani@tecnoroll.it

Updated the ASI In sample schematics.

Added *CrestClipper*, *FilterGain*, *StaticDelay* commands.

Expanded *Trim* limits.

Added firmware upgrade warning.

Index


1. FLEXMOD BLOCK DIAGRAM	6
1.1. FLEXMOD-621	6
2. CONNECTORS AND PIN DESCRIPTION	7
3. SERIAL PORT USAGE	9
3.1. HELP.....	9
4. FLEXMOD SYSTEM CONFIGURATION	10
4.1. SAVE.....	10
4.2. CLEAR.....	10
4.3. REBOOT	10
4.4. BAUD	10
4.5. ECHO	10
4.6. GETFWVERSION	10
4.7. GETSN.....	11
4.8. WELCOME	11
4.9. GETTEMP	11
4.10. SETOVERTEMP	11
5. FLEXMOD-621 DVB-T SFN MODULATOR CONFIGURATION	12
5.1. FREQUENCY	12
5.2. SPECTRUM.....	12
5.3. RFTEST.....	12
5.4. RFPOWER	12
5.5. PRECORR	12
5.6. PRELOAD	12
5.7. PRELIST	13
5.8. FIRLOAD	13
5.9. FIRSELECT	13
5.10. FIRLIST	13
5.11. IQOFFSET.....	13
5.12. CRESTCLIPPER.....	13
5.13. FILTERGAIN	14
6. SFN MANAGEMENT AND STATUS COMMANDS	15
6.1. TXIDENTIFIER.....	15
6.2. LOCALFUNCT	15
6.3. CELLID	15
6.4. TIMEOFFSET.....	15
6.5. SUBNETWORK	15
6.6. SUBNETMAXDEL	15
6.7. FORCERESYNC	16
6.8. SETMAXDRIFT	16
6.9. SFNCLEANER.....	16
6.10. GETMODFLAGS	16
6.11. GETMAXDEL.....	16
6.12. GETTRSPDEL.....	16
6.13. GETMIPFUNC	17

6.14. MAINMONITOR.....	17
7. INPUT TRANSPORT STREAM AND GPS CONFIGURATION	18
7.1. SELINPUTASI	18
7.2. PPSEDGE	18
7.3. REF CLOCK	18
7.4. TRIM	18
7.5. STATICDELAY	18
8. FLEXMOD MODULE UPGRADE.....	19
8.1. FLASHFORMAT	19
8.2. UPGRADE	20
9. SAMPLE SCHEMATICS.....	21
9.1. ASI INPUT SAMPLE SCHEMATIC	21
9.2. ASI OUTPUT SAMPLE SCHEMATIC.....	22
9.3. FLAGS SPI SAMPLE SCHEMATIC.....	23
10. POWER SUPPLIES CHARACTERISTICS.....	24
11. ALPHABETICAL COMMAND LIST	25
12. TYPICAL OUTPUT CHARACTERISTICS	26
13. PACKAGING INFORMATION	27
APPENDIX A ‘TYPE’ DESCRIPTION FOR CONNECTOR PINS	28
APPENDIX B FLEXMOD PRODUCT IDENTIFICATION SYSTEM	29


1. FLEXMod Block Diagram

1.1. FLEXMod-621

The FLEXMod-621 is an ETSI EN 300 744/TS 101 191 compliant modulator with an integrated microprocessor, enhanced output filtering and a 1GHz output DAC.



2. Connectors and pin description



FLEXMod-621, Top view

Pin	Symbol	Type	Description
1	GNDA	P	Analog ground
2	1V8A	P	+1.8V Analog Power Supply
3	1V8	P	+1.8V Digital Power Supply
4	GND	P	Digital Ground
5	RSVD	-	Reserved
6	MAIN_ASI_IN	I _{LVDS+}	Main LDVS TS ASI Input. Requires a Cable equalizer and an adaptation network. See <i>ASI Input</i> on page 21 .
7		I _{LVDS-}	
8	Backup_ASI_IN	I _{LVDS+}	Backup LDVS TS ASI Input. Requires a Cable equalizer and an adaptation network. See <i>ASI Input</i> on page 21 .
9		I _{LVDS-}	
10	RSVD	-	Reserved
11	RSVD	-	Reserved
12	RSVD	-	Reserved
13	RSVD	-	Reserved
14	RSVD	-	Reserved
15	RSVD	-	Reserved
16	RSVD	-	Reserved
17	REF_10MHz	I ₃	10Mhz reference input

Pin	Symbol	Type	Description
18	GND	P	Digital Ground
19	1V2	P	+1.2V Digital Power Supply
20	3V3	P	+3.3V Digital Power Supply
21	TxD	O ₃	RS232 TX Line
22	RxD	I ₃	RS232 RX Line
23	PPS_INPUT	I ₃	1 Pulse-per-second reference clock input (GPS).
24	3V3	P	+3.3V Digital Power Supply
25	1V2	P	+1.2V Digital Power Supply
26	GND	P	Digital Ground
27	RSVD	O ₃	Reserved
28	RSVD	O ₃	Reserved
29	RSVD	O ₃	Reserved
30	RSVD	O ₃	Reserved
31	RSVD	O ₃	Reserved
32	RSVD	O ₃	Reserved
33	RSVD	O ₃	Reserved
34	RSVD	O ₃	Reserved
35	FLAGS_CLK	O ₃	Flags SPI Clock Signal ⁽¹⁾
36	FLAGS_DATA	O ₃	Flags SPI Data Signal ⁽¹⁾
37	ASI_OUT	O _{LVDS-}	LDVS TS ASI Output. Requires an adaptation network and a Cable Driver. See <i>ASI Output</i> on page 22 for more information.
38		O _{LVDS+}	
39	FLAGS_LD	O ₃	Flags SPI Load Signal ⁽¹⁾
40	GND	P	Digital Ground
41	3V3	P	+3.3V Digital Power Supply
42	3V3A	P	+3.3V Analog Power Supply
43	GNDA	P	Analog ground
44	GNDA	P	Analog ground
45	IFOUT	O _a	Analog output (current mode): Open source DAC complementary output source. Connect through 50Ω to GNDA.
46	GNDA	P	Analog ground
47	IFOUT	O _a	Analog output (current mode): Open source DAC output source. Connect through 50Ω to GNDA.
48	GNDA	P	Analog ground

See Appendix A on page 28 for *type* description.

(¹) See *Flags SPI sample schematic* on page 23

3. Serial port usage

The Rs232 serial port allows the configuration and the operation of the FLEXMod boards. This serial port normally operates at 115200 bps, 8 data bits, 1 stop bit, no parity but the operating baud rate can be changed using the *Baud* command. Regardless of the setting done with the *Baud* command, the FLEXMod-621 will always boot using a baud rate of 115200 bps.

This serial port normally echoes back to the terminal the characters received. When this is not desirable (because you are using a microcontroller, for example) echoing can be disabled using the *ECHO* command (see *Echo* on page 10).

Most of the command used to set values with one or more parameters, returns the current configured value if issued without any parameter.

A list of available commands can be obtained using the *HELP* command.

3.1. HELP

Used for: FLEXMod Help.
Parameters: None
Example: Help ↵

4. FLEXMod system configuration

The configuration setup of the operating parameters is stored in an onboard EEPROM. Commands change the current operating parameters in ram: to make any configuration change permanent, the *SAVE* command (see below) should be issued.

4.1. Save

Used for: Saves operating parameters into EEPROM.
Parameters: None
Example: Save ↵
Notes: -.

4.2. Clear

Used for: Clears EEPROM values to factory defaults.
Parameters: None
Example: Clear ↵
Notes: The factory defaults will be loaded and the system rebooted.

4.3. Reboot

Used for: Restart the FLEXMod.
Parameters: Option
Example: Reboot ↵ *(Reboot both FPGA and microprocessor)*
 Reboot 0 ↵ *(Reboot microprocessor only)*
Notes: -.

4.4. Baud

Used for: Changes the serial port baud rate.
Parameters: BaudRate
Example: Baud 9600 ↵
 Baud 115200 ↵
Notes: Boot baud rate will always be 115200. Nearly all baud rates can be selected up to 3Mbps.

4.5. Echo

Used for: Activates/Deactivate character echoing.
Parameters: 0 or 1
Example: Echo 0 ↵
 Echo 1 ↵
Notes: Echoing could be disabled to ease the use of a microcontroller. When operating the FLEXMod using a terminal program, having the FLEXMod echoing the characters back simplifies its use.

4.6. GetFWVersion

Used for: Query FLEXMod product name and firmware version.

Parameters: None
Example: GetFWVersion ←
Notes: Return value is:
FLEXMod-SFN
Version:x.xx

4.7. GetSN

Used for: Query FLEXMod serial number.
Parameters: None
Example: GetSN ←
Notes: Return value is:
SN: xx.xx.xx.xx.xx.xx.xx

4.8. Welcome

Used for: Activates/Deactivate welcome message.
Parameters: 0 to 1
Example: Welcome 0 ← *(Welcome message disabled)*
 Welcome 1 ← *(Standard welcome message)*
Notes: There is a special welcome message sent by the FLEXMod when receiving the first ENTER (CR, 0x0D) character after a boot. This is helpful when using the FLEXMod connected to a USB serial port since the original power-up message will be lost because the USB is not yet connected. It is advisable to disable this welcome message when operating the FLEXMod using a microcontroller.

4.9. GetTemp

Used for: Display currently FlexMOD temperature.
Parameters: None
Example: GetTemp ←
Notes: The temperature is shown in Celsius degree.

4.10. SetOvertemp

Used for: Set point for output alarm signal.
Parameters: -128 to 127
Example: SetOvertemp 75 ←
Notes: Temperature is set in Celsius degrees. Output LED will light when FlexMOD temperature is above this set value.

5. FLEXMod-621 DVB-T SFN modulator configuration

5.1. Frequency

Used for: Set DVB-T SFN output frequency.
 Parameters: 0 to 50000000.
 Example: Freq 36000000 ↵

5.2. Spectrum

Used for: Set output spectrum.
 Parameters: 0 or 1
 Example: Spect 0 ↵
 Notes: Select 1 to invert the output spectrum.

5.3. RFTest

Used for: Force RF Output On.
 Parameters: [active], [chbw], [const], [carriers]
 Example: RFTest 1,8,64,8 ↵ *(Enable RFTest, 8MHz bandwidth, 64-QAM, 8K)*
 RFTest 1,8,4,2 ↵ *(Enable RFTest, 8MHz, QPSK, 2K)*
 RFTest 1 ↵ *(Enable RFTest with last settings)*
 RFTest 0 ↵ *(Disable RFTest)*
 Notes: Since the RF output is not enabled until all the SFN synchronization is achieved, it is not possible to see any output until the full SFN setup has been completed. To test the system, it is possible to activate the output regardless of the SFN status using this command.

5.4. RFPower

Used for: Set RF output power.
 Parameters: 0 to 255
 Example: Power 128 ↵
 Notes: Programs the AD 9957 output power. Default value is 128.

5.5. PreCorr

Used for: Enables/Disables the digital precorrector function.
 Parameters: 0 or 1
 Example: Precorr 0 ↵ *(Disables digital precorrector)*
 Precorr 1 ↵ *(Enables digital precorrector)*
 Notes: -.

5.6. PrecLoad

Used for: Loads Digital precorrector table.
 Parameters: 1 or 2
 Example: PrecLoad 1 ↵ *(Prepare for loading the Amplitude correction table)*
 PrecLoad 2 ↵ *(Prepare for loading the Phase correction table)*

Notes: Both amplitude and phase correction tables require 1024 coefficients entered one per line, 0 to $2^{17}-1$ for amplitude, -2^{17} to $2^{17}-1$ for phase.
 Amplitude coefficients are scaled by 2^{17} , so amplitude correction is 0 to $(2^{17}-1)/2^{17}=0.99999$, while phase coefficients are scaled by $2^{17}/180$ degrees, so phase correction is $(-2^{17})/(2^{17}/180)=-180$ degrees to $(2^{17}-1)/(2^{17}/180)=179.99$ degrees.

Notes: -.

5.7. PrecList

Used for: Shows the loaded precorrector table.

Parameters: 1 or 2

Example: PrecList 1 ↵

(Shows Amplitude precorrection table)

PrecList 2 ↵

(Shows Phase precorrection table)

Notes: -.

5.8. FirLoad

Used for: Load the linear precorrector fir filter coefficients.

Parameters: None

Example: FirLoad ↵

Notes: With this command you can load 181 18 Bit wide coefficient numbers (one per line) for a 181 TAP FIR Filter.

5.9. FirSelect

Used for: Select which FIR filter should be used.

Parameters: 0 or 1

Example: FirSelect 0 ↵

(Select internal, standard, FIR filter)

FirSelect 1 ↵

(Select user loaded FIR filter)

Notes: -.

5.10. FirList

Used for: Shows the loaded FIR filter coefficients.

Parameters: None

Example: FirList ↵

(Shows current user loaded FIR filter coefficients)

-.

5.11. IQOffset

Used for: I/Q manual offset and balancing compensation.

Parameters: p1,p2

Example: IQOffset 12,18 ↵

Notes: p1 is the compensation value for 7MHz bandwidth, p2 is the compensation value for 6 and 8 MHz bandwidths.

5.12. CrestClipper

Used for: Set the Crest-Factor clipping level.

Parameters: CrestClippingFactor

Example: CrestClipper 0 \leftarrow

Notes: CrestClippingFactor is a number between 0 (no clipping, default value) to 255 (maximum crest clipping factor).

5.13. FilterGain

Used for: Internal filters gain.

Parameters: 0 to 65535

Example: FilterGain 32768 \leftarrow

Notes: This value is the internal filters gain. Value is scaled by 2^{15} (32768) so actual values are between 0 and 1.9999 ($65535/32768$). Default value is 32768 (Gain 1.0).

6. SFN management and status commands

6.1. TxIdentifier

Used for: Set the TX identifier number.
 Parameters: 0 to 65535
 Example: TxIdentifier 0←

6.2. LocalFunct

Used for: Use Local or remote (From MIP) Functions.
 Parameters: 0 or 1
 Example: LocalFunct 0←
 Notes: When *LocalFunct* is set to 1, the CellID and TimeOffset (see below) are not read from the MIP, but set with the *CellID* and *TimeOffset* commands.

6.3. CellID

Used for: Set the local Cell Identifier.
 Parameters: 0 to 65535
 Example: CellID 44← *(Set the Cell ID to 44)*
 Notes: The value set with this command is ignored, unless the modulator is set to use local defined parameters with the *LocalFunct 1* command.

6.4. TimeOffset

Used for: Set an arbitrary SFN Startup Delay in 0.1 uSec step.
 Parameters: -32768 to 32767
 Example: TimeOffset 1000← *(Set a startup delay of 1ms)*
 Notes: The value set with this command is ignored, unless the modulator is set to use local defined parameters with the *LocalFunct 1* command.

6.5. SubNetwork

Used for: Enable the SFT-DVB-T to SFN-DVB-T repeater mode.
 Parameters: 0 or 1
 Example: SubNetwork 1← *(Enable repeater mode)*
 Notes: SFN repeater mode is the mode used when the input TS comes from a received SFN network. The original network 'MaxDelay' is zeroed and a new, local, delay (set with the *SubNetMaxDel* command) is used.

6.6. SubNetMaxDel

Used for: Set the Subnetwork Max-Delay in 0.1 uSec step.
 Parameters: 50000 to 9999999
 Example: SubNetMaxDel 1000000← *(Set the subnetwork Max Delay to 100ms)*
 Notes: This value is not used unless the FlexMOD is in repeater (SubNetwork) mode.

6.7. ForceResync

Used for: Force the SFN modulator to Resync.
 Parameters: None
 Example: ForceResync ↵

6.8. SetMaxDrift

Used for: Set the maximum allowed drift between Megaframe & PPS in nSec.
 Parameters: 2000 to 32767
 Example: SetMaxDrift 25000 ↵ *(Set the maximum allowed drift to 25μS)*
 Notes: If the drift between the MegaFrame and the Pulse Per Second exceeds the maximum value set, the modulator is stopped and restarted when a new sync has been achieved.

6.9. SfnCleaner

Used for: Enable/Disable the SFN Null Packet cleaner.
 Parameters: 0 or 1
 Example: SfnCleaner 1 ↵ *(Enable SFN Cleaner mode)*
 Notes: When other FlexMOD modulator are used to create a SFN compatible link, with the transmitting FlexMOD set in SFN mode, inserted NULL packets are specially signed. The SFN Cleaner, if activated, removes these specially signed packets in order to restore the original, SFN, transport stream.

6.10. GetModFlags

Used for: Return the current modulator status flags.
 Parameters: None
 Example: GetModFlags ↵
 Notes: Returned flags are:
SFN, MIP, PPS, OSC, TSI, TS2, CTS, TPS
 All are 0 (indicating ‘not working’) or 1 (indicating ‘OK’) except TPS which are all the TPS bits. CTS is the Current TS used (0 = Main, 1 = Backup).
 An example of a working SFN modulator is:
1, 1, 1, 1, 1, 0, 0, 00978000

6.11. GetMaxDel

Used for: Return the Network MAX Delay in 0.1 uSec step.
 Parameters: None
 Example: GetMaxDel ↵
 Notes: The Network maximum delay as set in the MIP is returned.

6.12. GetTrspDel

Used for: Return the Network Transport Delay in nS.
 Parameters: None
 Example: GetTrspDel ↵
 Notes: The current network transport delay as measured by the modulator is returned.

6.13. GetMipFunc

Used for: Return the Network MIP Functions.
 Parameters: None
 Example: `GetMipFunc`
 Notes: Returned functions are:
`TimeOffset, FreqOffset, Power, CellID.`

6.14. MainMonitor

Used for: Show the current modulator status.
 Parameters: [ANSIMode],[RefreshRate]
 Example: `MainMonitor 0` (80x25 screen, maximum refresh rate)
`MainMonitor 1` (80x24 screen, maximum refresh rate –default option–)
`MainMonitor 0,2` (80x25 screen, refreshed every 2 seconds)
 Notes: With Windows Hyperterminal, use the 80x24 screen.

MIP Info: DETECTED OK			TPS Info:		SFN Launcher Info:	
Pointer = 0	Const = QPSK	STS = 0,402.857.4			ARRIVAL = 0,870.009.6	
STS = 0,590.825.4	Alpha = NOT HIER	Max Delay = 0,900.000.0	FEC = 1/2	Guard = 1/8	STARTUP DELAY = 0,430.411.5	BUFFER SIZE = 288 Kbytes
Max Delay = 0,900.000.0		Trsp.Delay = 0,462.581.0		Carrier = 8K	SFN MODULATOR = RUNNING	
Trsp.Delay = 0,462.581.0		MF Main TS = 2016			LAUNCHER = IDLE	
MF Main TS = 2016	CH BW = 8MHz	MF Bkp TS = 0	Interl. = Native		STATE MACHINE = OK	
MF Bkp TS = 0		Expected = 2016	TS Pri. = High		MAX DELAY = OK	
PPS Info: DETECTED OK			TSlice. = Yes		RAM BUFFER = OK	
Counter Error = -66	MPE_FEC = Yes	Average Error = -60			RAM ALIGNMENT = OK	
Current 10MHz = 100000000	Master Oscillator Info:			RefClk = 10 MHz		
	Abs.SFN Drift = -13 nS	OSCILLATOR = VCXO		VCXO = 2056.00		
	Oscill. Drift = 0 Hz			COMPENS.= Freq.		
TS Info: DETECTED OK			Max Pos.Jitter = 0 nS	WARMUP = OK		
Master TS = 188 Byte		TS mode = Continuous	Max Neg.Jitter = 0 nS	LOCKED = LOCKED		
TS mode = Continuous	Total Jitter = 0 nS			DRIFT = OK		
TS Errors = 0						
Backup TS = NO CARRIER						
TS mode = -----	Local Info (TxID: 0): --> FROM MIP					
TS Errors = 100	SubNetwork = No			Cell ID = 0		
Current TS = MAIN	SubnetMaxDelay = 0,100.000.0			Freq Off = 0		
	Time Offset = 0.0			TX Power = 0		

Modulator status page example

7. Input Transport Stream and GPS configuration

7.1. SelInputASI

Used for: Select the ASI Input Interface.

Parameters: 0, 1 or 2

Example: SelInputAsi 0 ↵ *(Select Main ASI input)*
 SelInputAsi 1 ↵ *(Select Backup ASI input)*
 SelInputAsi 2 ↵ *(Auto input selection)*

Notes: If Automatic input selection is selected, the FlexMOD will use the Main ASI input, switching to the Backup input if the Main ASI input fails.

7.2. PpsEdge

Used for: Set the PPS edge detection.

Parameters: 0 or 1

Example: PpsEdge 0 ↵ *(Select Falling edge)*
 PpsEdge 1 ↵ *(Select Rising edge)*

7.3. RefClock

Used for: Select the modulator reference clock input.

Parameters: 0 to 3

Example: RefClock 0 ↵ *(Do not use to 10MHz reference clock)*
 RefClock 1 ↵ *(Use the dedicated input pin)*
 RefClock 2 ↵ *(Use the Main ASI input)*
 RefClock 3 ↵ *(Use the Backup ASI input)*

Notes: If the 10MHz reference clock is not used, the FlexMOD will frequency lock to the PPS input, but the output will have higher jitter and drift.
 If the Main or Backup ASI inputs are used, the ASI input function will be disabled, and a differential 10MHz clock should be given to the LVDS input pins.

7.4. Trim

Used for: Compensate for the modulator startup time and PPS datapath delay.

Parameters: -5000000 to 5000000

Example: Trim 38 ↵ *(Set the delay to 3.8μs)*
 Notes: Unit is 0.1μs.

7.5. StaticDelay

Used for: Extra SFN startup delay added to the incoming Time Offset value.

Parameters: -9999999 to 9999999

Example: StaticDelay 110 ↵ *(Set the delay to 11.0μs)*
 Notes: Unit is 0.1μs, default is 0.

8. FLEXMod module upgrade

IMPORTANT NOTE:

If the module has the “**FLEXMod 2.0 FPGA Boot Loader**” installed, do not use the following procedure to upgrade.

Please refer to the “**FLEXMod 2.0 FPGA Boot Loader**” documentation for a fail-safe and faster upgrade procedure.

The FLEXMod firmware can be user upgraded if needed.

The upgrade procedure is performed with the following steps:

1. Change the baud rate to something faster than 115200. This step is not necessary (the upgrade can also be done at any baud rate) but since the firmware is quite long it is advisable to do this.
2. Issue the *FlashFormat 741852* command which erases the onboard serial flash containing the firmware.
3. Wait for the FLEXMod signaling the end of the flash erasing procedure (it takes normally 10 seconds)
4. Issue the *Upgrade 741852* command and upload the new firmware using the XMODEM protocol.
5. When the upload has been completed, wait for the acknowledge that the upgrade has been successfully completed.
6. Power off and then back on the FLEXMod.

Please note:

Should the procedure fail for any reason, perform the procedure again starting from step 2. **Do not** power off the board since the flash has been erased (or contains an invalid firmware) and hence the board will not work (and could also, in rare occasions, be damaged). Should this happen, the board has to be returned to factory for reprogramming

Note also that this procedure will erase the welcome/manufacturer message.

8.1. FlashFormat

Used for:	Erases the onboard serial flash.
Parameters:	741852
Example:	FlashFormat ↵
Notes:	<p>The 741852 parameter is a constant value used to avoid the risk of issuing this command by chance.</p> <p>Do not erase the flash if you are not ready to perform an upgrade procedure.</p> <p>After the flash has been erased, the FLEXMod will not be able to boot.</p> <p>This will also erase the welcome/manufacturer message.</p>


8.2. Upgrade

Used for: XMODEM upload of a new firmware.
Parameters: 741852
Example: Upload ↲
Notes: Any terminal software capable of the XMODEM protocol can be used.
The 741852 parameter is a constant value used to avoid the risk of issuing this command by chance.

9. Sample schematics

9.1. ASI Input sample schematic


The LDVS TS ASI Input requires a cable equalizer and an adaptation network in order to adjust input levels. Note that ASI_IN is a LVDS signal, so route accordingly. The following schematics is a typical application ASI input:




Typical ASI input

9.2. ASI Output sample schematic

The LDVS TS ASI Output requires an adaptation network in order to adjust input levels and an output driver. Note that ASI_OUT is a LVDS signal, so route accordingly. The following schematics is a typical application ASI output:



9.3. Flags SPI sample schematic



Bit	Flag
D0	Boot OK
D1	OverTemp
D2	SFN Unlock
D3	Frequency Unlock
D4	High Priority TS DCD
D5	High Priority TS 204/188
D6	High Priority TS Burst
D7	High Priority TS Overflow

Bit	Flag
D8	Low Priority TS DCD
D9	Low Priority TS 204/188
D10	Low Priority TS Burst
D11	Low Priority TS Overflow
D12	Spare / Unused
D13	Spare / Unused
D14	Spare / Unused
D15	Spare / Unused


10. Power supplies characteristics

SYMBOL	PARAMETER	CONDITIONS	MIN	TYP.	MAX	UNIT
1V2	Core voltage			640		mA
1V8	DAC voltage			330		mA
1V8A	Analog voltage			110		mA
3V3	I/O voltage			TBD		mA
3V3A	Analog voltage			90		mA


11. Alphabetical command list

B		M	
Baud	10	MainMonitor.....	17
C		P	
CellID.....	15	PpsEdge.....	18
Clear.....	10	PrecList.....	13
CrestClipper.....	13	PrecLoad.....	12
E		PreCorr	12
Echo	10	R	
F		Reboot	10
FilterGain.....	14	RefClock.....	18
FirList.....	13	RFPower.....	12
FirLoad.....	13	RFTest	12
FirSelect	13	S	
FlashFormat.....	19	Save	10
ForceResync	16	SellInputASI	18
Frequency	12	SetMaxDrift	16
G		SetOvertemp	11
GetFWVersion.....	10	SfnCleaner	16
GetMaxDel	16	Spectrum.....	12
GetMipFunc.....	17	StaticDelay	18
GetModFlags	16	SubNetMaxDel	15
GetSN.....	11	SubNetwork.....	15
GetTemp.....	11	T	
GetTrspDel	16	TimeOffset.....	15
H		Trim.....	18
HELP.....	9	TxIdentifier	15
I		U	
IQOffset.....	13	Upgrade	20
L		W	
LocalFunct.....	15	Welcome.....	11

12. Typical output characteristics




Typical output spectrum at 36MHz




Typical constellation at 64QAM and output MER

13. Packaging information



Units: mm [mils]
Controlling dimensions: mm




Top View

Bottom View

Appendix A ‘Type’ description for connector pins

Type	Description
I _a	Analog input
I ₅	5V compatible input
I ₃	3.3V compatible input
I _{3/5}	3.3V compatible input, 5V tolerant
I _{LVDS±}	Positive/Negative LVDS input
O _a	Analog output
O ₃	3.3V output
O ₅	5V output
OC ₃	3.3V output, Open Collector
O _{LVDS±}	Positive/Negative LVDS output
P	Power supply line
P _o	Power supply output line

Appendix B FLEXMod Product Identification System



Modulator type	
0	Unprogrammed hardware
1	DVB-T MFN: <i>ETSI EN 300 744</i> compliant COFDM modulator.
2	DVB-S: <i>ETSI EN 300 421</i> compliant QPSK modulator.
3	DVB-C: <i>ETSI EN 300 429</i> compliant QAM modulator.
4	ATSC (A/53) compliant modulator.
5	DVB-S/S2: <i>ETSI EN 300 421/302 307</i> compliant QPSK/8PSK/16,32APSK modulator.
6	DVB-T SFN: <i>ETSI EN 300 744/TS 101 191</i> compliant COFDM modulator.
7	SFN Adapter/MIP Inserter
8	Aspect Ratio corrector and EPG inserter
9	Transport Stream Converter/Remultiplexer
AV1	DVB-T MFN: ETSI EN 300 744 compliant COFDM TR391AV Controller
AV2	DVB-S: ETSI EN 300 421 compliant QPSK TR391AV Controller
AV3	DVB-C: ETSI EN 300 429 compliant QAM TR391AV Controller
CM0	Transport stream Combiner

Technology	
0	Reference clock: 1.024 GHz.
1	Professional tunable reference clock (VCXO): 1.024 GHz.
2	Professional tunable reference clock (VCXO): 1.024 GHz and SFN input FIFO
8	Reference clock: 16 MHz.

Options

P	Premium type.
N	Unboxed (naked) version.
NP	Unboxed (naked) version, no pins, panelized

Examples:

FLEXMod-101 Consumer grade DVB-T modulator, reference clock 1.024GHz, HW revision 1

FLEXMod-281 Consumer grade DVB-S modulator, reference clock 16MHz, HW revision 1