

**Tecnoroll BMB srl**

Via Olona 9, 21040 Veduggio Olona VA

[www.tecnoroll.it](http://www.tecnoroll.it)

# **FLEXMod-811**

**module**

Connectors, pin description and programming protocol

Rev A, September, 10th 2012

Hardware revision 2.00

Firmware version 0.12

1. The use of this product in conformity with the DVB Standard is prohibited in any case, unless the license of patents applicable to the DVB patent group is granted.
2. It's the purchaser's duty to check which patents with potentially payable author's rights are used in his/her own final project and act accordingly with the bodies in charge.
3. The contents of this manual are subject to change without notice.
4. Of the specifications described in this manual, the functions and performance the supply of which is assured with this product are only those that can be confirmed with the separate Basic Firmware attached.
5. When the product or information described in this manual is used, our company does not guarantee or grant any license of the intellectual property rights and other rights of our company or of third parties. If any problems concerning the ownership rights of third parties attributable to the above use occur, our company will not be responsible for them.
6. Since the product described in this manual was not developed specially for equipment related to human life, those who intend to use it for equipment whose failure or malfunction may directly threaten human life or endanger the human body or for special applications requiring high reliability (such as aerospace, nuclear power control, submarine repeaters, travel control, and medical equipment for life support) must consult our sales responsible personnel in advance. Our company will not be responsible for any damages that may occur due to such use without consulting us.
7. Although our company is endeavoring to improve quality and enhance reliability, semiconductor products will fail with a certain probability. Users are requested to pay due attention to safe design techniques such as redundant design, preventive measures against the spreading of fire, over-current, and malfunctions, so that failure of the products described in this manual will not result in accidents leading to injury or death, fire, or social damage.
8. The product described in this manual is not designed to be radiation-resistant.
9. This board is just an 'electronic component' that cannot work in a standalone mode, therefore all the tests and qualifications for electromagnetic compatibility, all the CE certifications and any other regulations concerning the final product implemented by the customer are to be carried out by the customer himself referring to the final product for which this electronic component has been used.

**Revision history:**

**Rev A, September, 10th 2012, abesani@tecnoroll.it**  
First release

# Index


<b>1.</b>	<b>FLEXMOD BLOCK DIAGRAM.....</b>	<b>6</b>
1.1.	FLEXMOD-811.....	6
<b>2.</b>	<b>CONNECTORS AND PIN DESCRIPTION.....</b>	<b>7</b>
<b>3.</b>	<b>SERIAL PORT USAGE.....</b>	<b>10</b>
3.1.	HELP.....	10
<b>4.</b>	<b>FLEXMOD SYSTEM CONFIGURATION.....</b>	<b>11</b>
4.1.	SAVE.....	11
4.2.	CLEAR.....	11
4.3.	REBOOT.....	11
4.4.	BAUD.....	11
4.5.	ECHO.....	11
4.6.	HEXMODE.....	11
4.7.	GETFWVERSION.....	12
4.8.	GETSN.....	12
4.9.	WELCOME.....	12
4.10.	GETTEMP.....	12
4.11.	TEMPALARM.....	12
<b>5.</b>	<b>TIME AND DATE CONFIGURATION.....</b>	<b>13</b>
5.1.	CLOCKSET.....	13
5.2.	CLOCKGET.....	13
5.3.	TOTSETOFFSETDESCRIPTOR.....	13
<b>6.</b>	<b>EPG CONFIGURATION COMMANDS.....</b>	<b>14</b>
6.1.	TSID.....	14
6.2.	ONID.....	14
6.3.	EITEVENT.....	14
6.4.	EITCLEARALL.....	15
6.5.	EITCLEAREVENT.....	15
<b>7.</b>	<b>ASPECT RATIO RELATED COMMANDS.....</b>	<b>16</b>
7.1.	ARFixSET.....	16
7.2.	ARFixLIST.....	16
<b>8.</b>	<b>INTERACTIVE CONFIGURATION, STATUS AND MISC COMMANDS.....</b>	<b>17</b>
8.1.	TsMON.....	17
8.2.	EASYVIEW.....	17
8.3.	KILLPID.....	17
<b>9.</b>	<b>TRANSPORT STREAM I/O CONFIGURATION.....</b>	<b>18</b>
9.1.	ASIINPUT.....	18
9.2.	TSINPUT.....	18
9.3.	SELINPUT.....	18
9.4.	ASIOUTPUT.....	18
9.5.	ASIOURATE.....	19
9.6.	TSOUTPUT.....	19

- 10. FLEXMOD MODULE UPGRADE..... 20**
  - 10.1. FLASHFORMAT ..... 20
  - 10.2. UPGRADE ..... 20
- 11. SAMPLE SCHEMATICS..... 22**
  - 11.1. ASI INPUT SAMPLE SCHEMATIC ..... 22
  - 11.2. ASI OUTPUT SAMPLE SCHEMATIC..... 23
- 12. POWER SUPPLIES CHARACTERISTICS..... 24**
- 13. ALPHABETICAL COMMAND LIST ..... 25**
- 14. PACKAGING INFORMATION ..... 26**
- APPENDIX A 'TYPE' DESCRIPTION FOR CONNECTOR PINS ..... 27**
- APPENDIX B FLEXMOD PRODUCT IDENTIFICATION SYSTEM ..... 28**


# 1. FLEXMod Block Diagram

## 1.1. FLEXMod-811

The FLEXMod-811 is a ETSI EN 300 468 compliant EPG inserter and optionally a ISO/IEC 13818-2 compliant aspect ratio modifier/fixer.



## 2. Connectors and pin description



FLEXMod-811, Top view

Pin	Symbol	Type	Description
1	GND	P	Digital Ground
2	1V8	P	+1.8V Digital Power Supply
3	1V8	P	+1.8V Digital Power Supply
4	GND	P	Digital Ground
5	REF_CLOCK	O <sub>3</sub>	Optional 27 MHz Reference Clock Output
6	ASI_IN	I <sub>LVDS+</sub>	LDVS TS ASI Input. Requires a Cable equalizer and an adaptation network. See <i>ASI Input</i> on page 22 .
7		I <sub>LVDS-</sub>	
8	TSin_CLK	I <sub>3</sub>	Transport Stream Input CLOCK signal
9	TSin_VALID	I <sub>3</sub>	Transport Stream Input VALID signal
10	TSin_D0	I <sub>3</sub>	Transport Stream Input Data line, bit 0
	TSin_D7		Transport Stream Input Data line, bit 7 <sup>(1)</sup>
11	TSin_D1	I <sub>3</sub>	Transport Stream Input Data line, bit 1
	TSin_D6		Transport Stream Input Data line, bit 6 <sup>(1)</sup>
12	TSin_D2	I <sub>3</sub>	Transport Stream Input Data line, bit 2
	TSin_D5		Transport Stream Input Data line, bit 5 <sup>(1)</sup>
13	TSin_D3	I <sub>3</sub>	Transport Stream Input Data line, bit 3
	TSin_D4		Transport Stream Input Data line, bit 4 <sup>(1)</sup>

Pin	Symbol	Type	Description
14	TSin_D4	I <sub>3</sub>	Transport Stream Input Data line, bit 4
	TSin_D3		Transport Stream Input Data line, bit 3 <sup>(1)</sup>
15	TSin_D5	I <sub>3</sub>	Transport Stream Input Data line, bit 5
	TSin_D2		Transport Stream Input Data line, bit 2 <sup>(1)</sup>
16	TSin_D6	I <sub>3</sub>	Transport Stream Input Data line, bit 6
	TSin_D1		Transport Stream Input Data line, bit 1 <sup>(1)</sup>
17	TSin_D7	I <sub>3</sub>	Transport Stream Input Data line, bit 7
	TSin_D0		Transport Stream Input Data line, bit 0 <sup>(1)</sup>
18	GND	P	Digital Ground
19	1V2	P	+1.2V Digital Power Supply
20	3V3	P	+3.3V Digital Power Supply
21	TxD	O <sub>3</sub>	RS232 TX Line
22	RxD	I <sub>3</sub>	RS232 RX Line
23	RSVD	-	Reserved
24	3V3	P	+3.3V Digital Power Supply
25	1V2	P	+1.2V Digital Power Supply
26	GND	P	Digital Ground
27	TSout_D7	O <sub>3</sub>	Transport Stream Output Data line, bit 7
	TSout_D0		Transport Stream Output Data line, bit 0 <sup>(2)</sup>
28	TSout_D6	O <sub>3</sub>	Transport Stream Output Data line, bit 6
	TSout_D1		Transport Stream Output Data line, bit 1 <sup>(2)</sup>
29	TSout_D5	O <sub>3</sub>	Transport Stream Output Data line, bit 5
	TSout_D2		Transport Stream Output Data line, bit 2 <sup>(2)</sup>
30	TSout_D4	O <sub>3</sub>	Transport Stream Output Data line, bit 4
	TSout_D3		Transport Stream Output Data line, bit 3 <sup>(2)</sup>
31	TSout_D3	O <sub>3</sub>	Transport Stream Output Data line, bit 3
	TSout_D4		Transport Stream Output Data line, bit 4 <sup>(2)</sup>
32	TSout_D2	O <sub>3</sub>	Transport Stream Output Data line, bit 2
	TSout_D5		Transport Stream Output Data line, bit 5 <sup>(2)</sup>
33	TSout_D1	O <sub>3</sub>	Transport Stream Output Data line, bit 1
	TSout_D6		Transport Stream Output Data line, bit 6 <sup>(2)</sup>
34	TSout_D0	O <sub>3</sub>	Transport Stream Output Data line, bit 0
	TSout_D7		Transport Stream Output Data line, bit 7 <sup>(2)</sup>
35	TSout_VALID	O <sub>3</sub>	Transport Stream Output VALID signal
36	TSout_CLK	O <sub>3</sub>	Transport Stream Output CLOCK signal
37	ASI_OUT	O <sub>LVDS-</sub>	LDVDS TS ASI Output. Requires an adaptation network and a Cable Driver. See <i>ASI Output</i> on page 23 for more information.
38		O <sub>LVDS+</sub>	
39	TSout_PSYNC	O <sub>3</sub>	Transport Stream Output PSYNC signal
40	GND	P	Digital Ground
41	3V3	P	+3.3V Digital Power Supply
42	3V3	P	+3.3V Digital Power Supply



<b>Pin</b>	<b>Symbol</b>	<b>Type</b>	<b>Description</b>
43	GND	P	Digital Ground
44	GND	P	Digital Ground
45	RSVD	-	Reserved
46	GND	P	Digital Ground
47	RSVD	-	Reserved
48	GND	P	Digital Ground

See Appendix A on page 27 for *type* description.

<sup>(1)</sup> Use the *TSInput* command (see page 18) to select normal or reversed input bus.

<sup>(2)</sup> Use the *TSEOutput* command (see page 19) to select normal or reversed output bus.

### 3. Serial port usage

The Rs232 serial port allows the configuration and the operation of the FLEXMod boards.

This serial port normally operates at 115200 bps, 8 data bits, 1 stop bit, no parity but the operating baud rate can be changed using the *Baud* command. Regardless of the setting done with the *Baud* command, the FLEXMod-811 will always boot using a baud rate of 115200 bps.

This serial port normally echoes back to the terminal the characters received. When this is not desirable (because you are using a microcontroller, for example) echoing can be disabled using the *ECHO* command (see *Echo* on page 11).

Most of the command used to set values with one or more parameters, returns the current configured value if issued without any parameter.

A list of available commands can be obtained using the *HELP* command.

#### 3.1. HELP

Used for: FLEXMod Help.

Parameters: None

Example: Help ↵

## 4. FLEXMod system configuration

The configuration setup of the operating parameters is stored in an onboard EEPROM. Commands change the current operating parameters in ram: to make any configuration change permanent, the *SAVE* command (see below) should be issued.

### 4.1. Save

Used for: Saves operating parameters into EEPROM.  
Parameters: None  
Example: Save ↵  
Notes: -.

### 4.2. Clear

Used for: Clears EEPROM values to factory defaults.  
Parameters: None  
Example: Clear ↵  
Notes: The factory defaults will be loaded and the system rebooted.

### 4.3. Reboot

Used for: Restart the FLEXMod.  
Parameters: Option  
Example: Reboot ↵ *(Reboot both FPGA and microprocessor)*  
Reboot 0 ↵ *(Reboot microprocessor only)*  
Notes: -.

### 4.4. Baud

Used for: Changes the serial port baud rate.  
Parameters: BaudRate  
Example: Baud 9600 ↵  
Baud 115200 ↵  
Notes: Boot baud rate will always be 115200. Nearly all baud rates can be selected up to 3Mbps.

### 4.5. Echo

Used for: Activates/Deactivates character echoing.  
Parameters: 0 or 1  
Example: Echo 0 ↵  
Echo 1 ↵  
Notes: Echoing could be disabled to ease the use of a microcontroller. When operating the FLEXMod using a terminal program, having the FLEXMod echoing the characters back simplifies its use.

### 4.6. HexMode

Used for: Activates/Deactivates hexadecimal replies.

Parameters: 0 or 1  
 Example: HexMode 0 ↵  
 HexMode 1 ↵  
 Notes: Hexadecimal replies could be enabled to ease the processing by a microcontroller.

#### 4.7. GetFWVersion

Used for: Query FLEXMod product name and firmware version.  
 Parameters: None  
 Example: GetFWVersion ↵  
 Notes: Return value is:  
*FlexMOD 811 - EPG Inserter*  
*x, Version:x.xx*

#### 4.8. GetSN

Used for: Query FLEXMod serial number.  
 Parameters: None  
 Example: GetSN ↵  
 Notes: Return value is:  
*xx.xx.xx.xx.xx.xx.xx*

#### 4.9. Welcome

Used for: Activates/Deactivate welcome message.  
 Parameters: 0 to 1  
 Example: Welcome 0 ↵ *(Welcome message disabled)*  
 Welcome 1 ↵ *(Standard welcome message)*  
 Notes: There is a special welcome message sent by the FLEXMod when receiving by the first ENTER (CR, 0x0D) character after a boot. This is helpful when using the FLEXMod connected to a USB serial port since the original power-up message will be lost because the USB is not yet connected. It is advisable to disable this welcome message when operating the FLEXMod using a microcontroller.

#### 4.10. GetTemp

Used for: Display currently FlexMOD temperature.  
 Parameters: None  
 Example: GetTemp ↵  
 Notes: The temperature is shown in Celsius degree.

#### 4.11. TempAlarm

Used for: Set point for output alarm signal.  
 Parameters: 30 to 125  
 Example: TempAlarm 75 ↵ *(Set the alarm temperature to 75 °C)*  
 Notes: Temperature is set in Celsius degrees. When FlexMOD temperature is above this set a warning message will be displayed in the *GetTemp* command reply.

## 5. Time and Date configuration

### 5.1. ClockSet

Used for: Set the internal clock/calendar.  
 Parameters: Hour,Min,Seconds,Day,Month,Year  
 Example: ClockSet 15,54,00,25,9,2012 ← *(Set the clock at 15:54:00 -3:54:00pm-, September, 25<sup>th</sup> 2012)*  
 Notes: Clock must be set in UTC time.  
 Month should be given numeric, and years before 2000 are not accepted.

### 5.2. ClockGet

Used for: Reads the internal clock/calendar.  
 Parameters: [1]  
 Example: ClockGet ← *(Return 25 Sep 2012, 15:54:04)*  
 ClockGet 1 ← *(Return 15, 54, 9, 25, 9, 2012)*  
 Notes: The optional parameter 1 returns the current clock in a microcontroller friendly version: *Hour,Minutes,Seconds,Day,Month,Year.*

### 5.3. TOTSetOffsetDescriptor

Used for: Set or get the TOT Local Offset Time Descriptor.  
 Parameters: CountryCode, RegionID, LocalTimeOffsetHour, LocalTimeOffsetMin, DateNextChangeHour, DateNextChangeMin, DateNextChangeSec, DateNextChangeDay, DateNextChangeMonth, DateNextChangeYear, NextTimeOffsetHour, NextTimeOffsetMin  
 Example: TOTSetOffsetDescriptor ita, 0, 2, 0, 3, 0, 0, 28, 10, 2012, 1, 0 ←  
 Notes: The 12 parameters are as follow:  
 CountryCode: ISO 639-2 Alpha3 language code  
 RegionID: Region ID within the defined country. 0 in most countries  
 LocalTimeOffsetHour: Local time offset (to UTC time), hours  
 LocalTimeOffsetMin: Local time offset (to UTC time), minutes  
 DateNextChangeHour: Date of next change of TimeOffset, hours  
 DateNextChangeMin: Date of next change of TimeOffset, minutes  
 DateNextChangeSec: Date of next change of TimeOffset, seconds  
 DateNextChangeDay: Date of next change of TimeOffset, day (1-31)  
 DateNextChangeMonth: Date of next change of TimeOffset, month (1-12)  
 DateNextChangeYear: Date of next change of TimeOffset, year  
 NextTimeOffsetHour: Next time offset (to UTC time), hours  
 NextTimeOffsetMin: Next time offset (to UTC time), minutes  
 The TOT table broadcasts the time information required by the receivers to convert EPG times (always in UTC) into local times, accounting for the Daylight Saving Time, if present. To be able to always broadcast a correct information even when the DST begins or ends, the next Date/Time of change and the next Time Offset are required.

## 6. EPG Configuration commands

### 6.1. TSID

Used for: Set Transport Stream ID.  
 Parameters: TsID  
 Example: TSID 1 ↵  
 Notes: The Transport stream ID must be set correctly to the same value used in the incoming transport stream.

### 6.2. ONID

Used for: Set Original Network ID.  
 Parameters: OriginalNetworkID  
 Example: ONID 8572 ↵  
 Notes: The Original Network ID must be set correctly to the same value used in the incoming transport stream.

### 6.3. EITEvent

Used for: Set an EIT event.  
 Parameters: 0|1, ServiceID, EvtID, Hour, Min, Sec, Day, Month, Year, DurationHour, DurationMin, DurationSec, LangCode, EventName[, EventText]  
 Example: EITEvent 0,77,123,20,0,0,25,9,2012,1,0,0,ita,Event Name ↵ (“Now” event)  
 EITEvent 1,77,124,21,0,0,25,9,2012,2,0,0,ita,Event Name ↵ (“Next” event)  
 Notes: The 15 parameters are as follow:  
 0|1: 0=Now, 1=Next event. The texts *Now* or *Next* can be used in place of 0 or 1  
 ServiceID: The service ID this event refers to  
 EvtID: The ID for this event. Range 0 to 65535.  
 Hour: Time/date when this event begins: hours  
 Min: Time/date when this event begins: minutes  
 Sec: Time/date when this event begins: seconds  
 Day: Time/date when this event begins: day  
 Month: Time/date when this event begins: month  
 Year: Time/date when this event begins: year  
 DurationHour: Duration of this event: hours  
 DurationMin: Duration of this event: minutes  
 DurationSec: Duration of this event: seconds  
 LangCode: ISO 639-2 Alpha3 language code for this event  
 EventName: Name of this event  
 EventText: (optional) Text describing this event  
 The maximum length of EventName and EventText should not exceed 250 characters.  
 If there was an older event defined for this Service ID, the new event replaces the older one. It is not necessary to manually delete the old event.

**6.4. EITClearAll**

Used for: Clear all EIT events.  
Parameters: none  
Example: EITClearAll ↵  
Notes: All the programmed EIT events are deleted and no longer broadcast.

**6.5. EITClearEvent**

Used for: Clear an EIT event.  
Parameters: 0|1,ServiceID  
Example: EITClearEvent 0,77 ↵ *(Clear "Now" event for Service ID 77)*  
Notes: The 0|1 parameter is 0=Now, 1=Next event. The texts *Now* or *Next* can be used in place of 0 or 1.  
It is not necessary to delete an event before changing it. Just give the new EITEvent command.  
This command can be used to clear some event when NO events are to be broadcast.

## 7. Aspect Ratio related commands

### 7.1. ARFixSet

Used for: Modifies a MPEG2 video Aspect Ratio.

Parameters: PID,NewAR

Example: ARFixSet 256,3 ← *(Changes the AR for the Video PID 256 to 16:9)*  
ARFixSet 256,0 ← *(Disables AR modification for the Video PID 256)*

Notes: A maximum of 16 PIDs can be fixed.

The NewAR value is: 0=Disabled, 1=1:1, 2=4:3, 3=16:9, 4=2.21:1

### 7.2. ARFixList

Used for: List currently defined MPEG2 Video Aspect Ratio.

Parameters: none

Example: ARFixList ←




## 8. Interactive configuration, status and misc commands

### 8.1. TsMon

Used for: Show transport streams bitrates.  
 Parameters: None or 2  
 Example: TsMon ↵ *(Simple text output)*  
 TsMon 2 ↵ *(ANSI continuous monitoring)*  
 Notes: The *EasyView* command is the same as *TsMon 2*.

### 8.2. EasyView

Used for: Shows all functional system information.  
 Parameters: TIME  
 Example: EasyConfig ↵ *(Default refresh delay of 0.1s)*  
 EasyConfig 10 ↵ *(Refresh every 1 second)*  
 Notes: Refresh rate is in 0.1s resolution.



EasyView page example

### 8.3. KillPID

Used for: Set or get the PID killer configuration.  
 Parameters: SLOT,PID  
 Example: KillPID ↵ *(Report the PID killers status)*  
 KillPID 0,220 ↵ *(Pid 220 is removed from the TS, using slot 0)*  
 Notes: The KillPID command allows the removal of a generic PID from the TS.  
 10 slots are available, so a maximum of 10 PIDs can be removed from the TS.

## 9. Transport stream I/O configuration

### 9.1. ASIInput

Used for: Set or get ASI input format.  
 Parameters: MODE  
 Example: SetASIInput 0 ← *(ASI TS input disabled)*  
 SetASIInput 1 ← *(Select normal ASI TS input)*  
 SetASIInput 2 ← *(Select inverted ASI TS input)*

Notes: Inverted ASI inverts LVDS+ and LVDS- signals.  
 MODE: 0,1,2 (0 = Disabled, 1 = Normal, 2 = Inverted)  
 If this command is given without parameters, it returns both the current ASI input configuration and the current ASI input status.  
 This command configures the ASI input but does not select it. Use the *SelInput* command to select the ASI or Parallel input.

### 9.2. TSInput

Used for: Set or get parallel TS input format.  
 Parameters: EN,CLK,VAL,BUS,REF  
 Example: TSInput 1,1,1,0,0 ← *(Parallel TS input enabled, sample on clock rising edge, Valid active high, no reference clock out)*

Notes: The parameters are as follow:  
 EN: 0=Input disabled, 1=Input enabled  
 CLK: Sample on 0=falling, 1=rising clock edge  
 VAL: 0=Valid active low, 1=Valid active high  
 BUS: 0=Normal TS input, 1=Reversed TS input  
 REF: 27 MHz reference clock output, 0=No, 1=Yes  
 This command configures the Parallel input but does not select it. Use the *SelInput* command to select the ASI or Parallel input.

### 9.3. SelInput

Used for: Set or get input selection.  
 Parameters: Input  
 Example: SelInput 0 ← *(Parallel input selected)*  
 SelInput 1 ← *(ASI input selected)*

Notes: 0 selects parallel input, 1 selects ASI input.

### 9.4. ASIOutput

Used for: Select normal or inverted ASI TS output.  
 Parameters: MODE  
 Example: SetASIOutput 0 ← *(ASI TS output disabled)*  
 SetASIOutput 1 ← *(Select ASI TS output)*  
 SetASIOutput 2 ← *(Select inverted ASI TS output)*

Notes: Inverted ASI inverts LVDS+ and LVDS- signals.  
 MODE: 0,1,2 (0 = Disabled, 1 = Normal, 2 = Inverted)

**9.5. ASIOutRate**

Used for: Set or get ASI output rate.  
Parameters: 0,1-210000000  
Example: ASIOutRate 0 ← *(Uses input rate)*  
ASIOutRate 24000000 ← *(Set the output rate to 24Mbits)*  
Notes: When the parameter is 0, the Transport Stream rate is not changed: this requires enough free bandwidth already to be present in the TS to be able to insert the EIT tables correctly.

**9.6. TSOutput**

Used for: Set or get parallel TS output format.  
Parameters: EN,CLK,VAL,BUS,SYNC  
Example: TSInput 1,1,1,0,0 ← *(Parallel TS input enabled, sample on clock rising edge, Valid active high, no reference clock out)*  
Notes: The parameters are as follow:  
EN: 0=Output disabled, 1=Output enabled  
CLK: Change data on 0=rising, 1=falling clock edge  
VAL: 0=Valid active low, 1=Valid active high  
BUS: 0=Normal TS output, 1=Reversed TS output  
SYNC: 0=PSYNC active low, 1= PSYNC active high  
The Clock output is fixed at 27MHz.

## 10. FLEXMod module upgrade

### **IMPORTANT NOTE:**

If the module has the “FLEXMod 2.0 FPGA Boot Loader” installed, do not use the following procedure to upgrade.

Please refer to the “FLEXMod 2.0 FPGA Boot Loader” documentation for a fail-safe and faster upgrade procedure.

The FLEXMod firmware can be user upgraded if needed.

The upgrade procedure is performed with the following steps:

1. Change the baud rate to something faster than 115200. This step is not necessary (the upgrade can also be done at any baud rate) but since the firmware is quite long it is advisable to do this.
2. Issue the *FlashFormat 741852* command which erases the onboard serial flash containing the firmware.
3. Wait for the FLEXMod signaling the end of the flash erasing procedure (it takes normally 10 seconds)
4. Issue the *Upgrade 741852* command and upload the new firmware using the XMODEM protocol.
5. When the upload has been completed, wait for the acknowledge that the upgrade has been successfully completed.
6. Power off and then back on the FLEXMod.

### **Please note:**

Should the procedure fail for any reason, perform the procedure again starting from step 2. **Do not** power off the board since the flash has been erased (or contains an invalid firmware) and hence the board will not work (and could also, in rare occasions, be damaged). Should this happen, the board has to be returned to factory for reprogramming

#### **10.1. FlashFormat**

Used for: Erases the onboard serial flash.

Parameters: 741852

Example: FlashFormat ↵

Notes: The 741852 parameter is a constant value used to avoid the risk of issuing this command by chance.

Do not erase the flash if you are not ready to perform an upgrade procedure. After the flash has been erased, the FLEXMod will not be able to boot.

#### **10.2. Upgrade**

Used for: XMODEM upload of a new firmware.

Parameters: 741852

Example:

Upload ↵

Notes:


Any terminal software capable of the XMODEM protocol can be used.

The *741852* parameter is a constant value used to avoid the risk of issuing this command by chance.

# 11. Sample schematics

## 11.1. ASI Input sample schematic


The LDVS TS ASI Input requires a cable equalizer and an adaptation network in order to adjust input levels. Note that ASI\_IN is a LVDS signal, so route accordingly. The following schematics is a typical application ASI input:



Typical ASI input

### 11.2. ASI Output sample schematic

The LDVS TS ASI Output requires an adaptation network in order to adjust input levels and an output driver. Note that ASI\_OUT is a LVDS signal, so route accordingly. The following schematics is a typical application ASI output:



Typical ASI output

## 12. Power supplies characteristics


<b>SYMBOL</b>	<b>PARAMETER</b>	<b>CONDITIONS</b>	<b>MIN</b>	<b>TYP.</b>	<b>MAX</b>	<b>UNIT</b>
1V2	Core voltage			TBD		mA
1V8	DAC voltage			TBD		mA
3V3	I/O voltage			TBD		mA




### 13. Alphabetical command list

	<b>B</b>			
Baud .....		10	MIPFuncList .....	16
	<b>C</b>		MIPFuncPower .....	16
Clear .....		10	MIPFuncPrivate .....	16
	<b>E</b>		MIPFuncTimeOffset .....	16
EasyConfig .....		17	MIPMaxDelay .....	13
EasyFunctions .....		19	MIPPointer .....	13
EasyView .....		18	MIPStartUpDelay .....	22
Echo .....		10	MIPStatus .....	18
	<b>F</b>			<b>P</b>
FlagsMatrix .....		21	PPsEdge .....	21
FlashFormat .....		23	PPsWatchDog .....	14
FrequencyError .....		13		<b>R</b>
	<b>G</b>		Reboot .....	10
GetFWVersion .....		11	RefClock .....	21
GetSN .....		11		<b>S</b>
GetTemp .....		11	Save .....	10
	<b>H</b>		SelASIIInput .....	20
HELP .....		9	SelASIOOutput .....	20
HexMode .....		10	SetASIIInput .....	20
	<b>L</b>		SetASIOOutput .....	20
LedSPI .....		20		<b>T</b>
	<b>M</b>		TempAlarm .....	12
MIPConfigOptions .....		21	TestMode .....	14
MIPFuncBandwidth .....		15	TPSParms .....	13
MIPFuncCellID .....		15	TsMon .....	17
MIPFuncEnable .....		15		<b>U</b>
MIPFuncFreqOffset .....		15	Upgrade .....	23
				<b>W</b>
			Welcome .....	11


# 14. Packaging information



Units: mm [mils]  
Controlling dimensions: mm



Top View




Bottom View

## Appendix A ‘Type’ description for connector pins

Type	Description
I <sub>a</sub>	Analog input
I <sub>5</sub>	5V compatible input
I <sub>3</sub>	3.3V compatible input
I <sub>3/5</sub>	3.3V compatible input, 5V tolerant
I <sub>LVDS±</sub>	Positive/Negative LVDS input
O <sub>a</sub>	Analog output
O <sub>3</sub>	3.3V output
O <sub>5</sub>	5V output
OC <sub>3</sub>	3.3V output, Open Collector
O <sub>LVDS±</sub>	Positive/Negative LVDS output
P	Power supply line
P <sub>o</sub>	Power supply output line

## Appendix B FLEXMod Product Identification System



<b>Modulator type</b>	
0	Unprogrammed hardware
1	DVB-T MFN: <i>ETSI EN 300 744</i> compliant COFDM modulator.
2	DVB-S: <i>ETSI EN 300 421</i> compliant QPSK modulator.
3	DVB-C: <i>ETSI EN 300 429</i> compliant QAM modulator.
4	ATSC (A/53) compliant modulator.
5	DVB-S/S2: <i>ETSI EN 300 421/302 307</i> compliant QPSK/8PSK/16,32APSK modulator.
6	DVB-T SFN: <i>ETSI EN 300 744/TS 101 191</i> compliant COFDM modulator.
7	SFN Adapter/MIP Inserter
8	Aspect Ratio corrector and EPG inserter
9	Transport Stream Converter/Remultiplexer
AV1	DVB-T MFN: <i>ETSI EN 300 744</i> compliant COFDM TR391AV Controller
AV2	DVB-S: <i>ETSI EN 300 421</i> compliant QPSK TR391AV Controller
AV3	DVB-C: <i>ETSI EN 300 429</i> compliant QAM TR391AV Controller
CM0	Transport stream Combiner

<b>Technology</b>	
0	Reference clock: 1.024 GHz.
1	Professional tunable reference clock (VCXO): 1.024 GHz.
2	Professional tunable reference clock (VCXO): 1.024 GHz and SFN input FIFO
8	Reference clock: 16 MHz.

<b>Options</b>	
P	Premium type.
N	Unboxed (naked) version.
NP	Unboxed (naked) version, no pins, panelized

## Examples:

FLEXMod-101    Consumer grade DVB-T modulator, reference clock 1.024GHz, HW revision 1  
FLEXMod-281    Consumer grade DVB-S modulator, reference clock 16MHz, HW revision 1